

## Abstract

Metal oxide perovskites are increasingly popular for magnetic and optoelectronic applications in industrial purposes. In this study, structural magnetic and optical properties of  $\text{InCoO}_3$ , and  $\text{InFeO}_3$  were unearthed using the first principles of density functional theory. These materials exhibit semiconducting behavior with indirect bandgap energy. The high absorption coefficient, low reflectivity, and high optical conductivity make them suitable for photovoltaic and other optoelectronic and memory device applications. Among them,  $\text{InFeO}_3$  is more favorable for magnetic and optical applications.

## Introduction

In a quest for nanoparticles, solar cells, and enhanced optical and magnetic properties, perovskite materials suit flawlessly in that range. Perovskite materials contain properties like tunable bandgap, long charge diffusion length, good charge carrier mobility, low carrier recombination rate, high dielectric constant. They have high efficiency in photoconductor-based X-ray detectors, spectroscopy, acoustic wave signal processing, and image storage device. These materials are the class of material that bears the chemical structure of  $\text{ABO}_3$ .




Figure 1: Cubic Structure of  $\text{InCoO}_3$  and  $\text{InFeO}_3$

In this type of material, O is oxygen with (-2) ionic valence anion, and A and B metal cations give (+6) valence ion combined. Perovskite material family has numerous types of oxide form like transition metal oxides with

the general formula of  $ABO_3$ . One perovskite material is  $LiNbO_3$ . For that, we took  $LiNbO_3$ -like material  $InCoO_3$ ,  $InFeO_3$  and sampled magnetic and optical properties with DFT calculations.

## Computaion Method

For computing the magnetic and optical properties of  $InFeO_3$  and  $InCoO_3$ , we execute Density Functional Theory (DFT) simulations by Vienna ab initio Simulation Package (VASP). The unit cells of  $InCoO_3$  and  $InFeO_3$  in the cubic form are shown in Fig. 1, which we explored further. First, we perform structural relaxation. Then we execute static calculation for density of states, band, and optical properties of chosen materials. ‘




Figure 2: Band Structure Of  $InCoO_3$  and  $InFeO_3$

## Results

$InFeO_3$  and  $InCoO_3$  are cubic structures under the space group of  $Pm\bar{3}m$  (no. 221). We visualize the structures in VESTA (3D Visualization for Electronic and Structural Analysis). The unit cell of  $InCoO_3$  and  $InFeO_3$

constitutes five atoms (shown in Fig. 1). Fe or Co atoms hold the corner positions of the cubes (Wyckoff site (0,0,0)), In situated in the crystal's body-centered positions (Wyckoff site(0.5,0.5,0.5)). O occupies face-centered positions (Wyckoff site (0.5,0.5,0)). The electronic band structures and density of states(DOS) of relaxed InCoO3 and InFeO3 structures through PBE functional considering the GGA approximation. Band structures of InCoO3 and InFeO3 are shown in Fig. 2.

Zero-point energy is Fermi energy. Two structures show indirect bandgap and the range of the bandgap energy resembles that both the structures are metallic in nature. The outcome of the bandgaps and band structures of the examined materials confirm their wonder for photothermal, photovoltaic, and optoelectronic applications. InCoO3 and InFeO3 show the same bandgap. The density of states of atoms is shown in Fig. 3.




Figure 3: Density of States Of InCoO3 and InFeO3

The orbital projected density of states indicates at the Fermi level, the p-orbital of Co and Fe atom is the main benefactor. The optical properties of a material rely on many parts. Such as absorption spectra, concerning light energy and wavelength, reflectivity, refractivity index, dielectric constants,

and optical conductivity. We examined these properties with InCoO3 and InFeO3. The optical absorption coefficient indicates how much light penetrates the substance before being absorbed by the material. This is a piece of important knowledge for solar-energy conversion efficiency for practical application. In Fig. 4 energy and wavelength-dependent absorption profiles are demonstrated.




Figure 4: Absorption Of InCoO3 and InFeO3

Reflectivity is an optical property to understand the surface nature of the material. It defines how much energy reflects from incident energy on the surface. Fig 5 represents the optical reflectivity of InCoO3 and InFeO3.




Figure 5: Reflectivity Of InCoO3 and InFeO3

The dielectric constant values are used for determining how well optoelectronic devices work, defined as the response of a material to incident light energy. Higher dielectric values at a lower charge carrier recombination rate are deep in improving the optoelectronic device performance. The optical conductivity of a material specifies the electric conductivity of a photon from electromagnetic absorption. Fig 6 shows the dielectric constants of InCoO3 and InFeO3. Fig 7 shows us optical conductivity between InCoO3 and InFeO3.





Figure 6: Dielectric constants of InCoO3 and InFeO3





Figure 7: Optical Conductivity of InCoO3 and InFeO3

## Conclusion

We performed a study on  $\text{InCoO}_3$  and  $\text{InFeO}_3$  perovskite cubic materials using DFT simulations for their structural, optical, and dielectric properties.  $\text{InCoO}_3$  and  $\text{InFeO}_3$  structures show identical indirect bandgap while  $\text{InFeO}_3$  shows more magnetic than  $\text{InCoO}_3$ . Fe is a better contender than Co for optical absorption and optical conductivity. Both the material can be an excellent choice for various photovoltaic applications, memory devices, and more.